



**SCHEDA ATTREZZATURA PER MANUTENZIONE POMPE SERIE 44 - ALBERO FEMMINA**  
**MAINTENANCE TOOL CHART FOR PUMPS 44 SERIES - FEMALE SHAFT**

<b>PARTICOLARE DA SOSTITUIRE</b> <i>PART TO REPLACE</i>		<b>ATTREZZO ESTRAZIONE</b> <i>REMOVING TOOL</i>			<b>ATTREZZO INSERIMENTO</b> <i>INSERTION TOOL</i>		
<b>CODICE</b> <i>PART NO.</i>	<b>DESCRIZIONE</b> <i>DESCRIPTION</i>	<b>CODICE</b> <i>PART NO.</i>	<b>DESCRIZIONE</b> <i>DESCRIPTION</i>	<b>UTILIZZARE CON</b> <i>USE WITH</i>	<b>CODICE</b> <i>PART NO.</i>	<b>DESCRIZIONE</b> <i>DESCRIPTION</i>	<b>UTILIZZARE CON</b> <i>USE WITH</i>
90161400	OIL SEAL D. 20X30X5				27120600	OIL SEAL INSERTION TOOL	
90357200	OR Ø5.28x1.78 (2021)				26242300	O-RING MOUNTIN GUIDE	
96735000	WASHER 16X28X1				27124600 27124700	WASHER MOUNTING GUIDE WASHER MOUNTING STUD	
90262000	SEAL D. 15x25x5/3.1 H.P.	26407400	EXTRACTION SOCKET D. 15	USE WITH EXTRACTOR 26019400	26242400	PACKING INSERTION GUIDE	USE WITH STUD 26242500
90268200	SEAL D.18x30x6/3,5 H.P.	27124900	EXTRACTION SOCKET D. 18	USE WITH EXTRACTOR 26019400	26083200	PACKING INSERTION GUIDE	USE WITH STUD 26134600
91856800	NEEDLE BEARING DHK 4520				27084200	NEEDLE BEARING MOUNTING STUD	
90169000	OIL SEAL D. 45X62X8				27084300	OIL SEAL INSERTION TOOL	